

Passenger Plugs and the Passenger List


Introduction

The Fleet Manager software includes support for the Black Passenger code-plug. This code-plug is used to identify passengers (non-drivers) getting onto and off of a vehicle. The software also includes a report, which lists the various times that a passenger identified himself/herself in the vehicle.

Creating Passengers

After acquiring a black Passenger code-plugs from your VDO dealer, you should add records for you passengers and the initialise the code-plugs.

Open the Fleet Manager Client application, then click the Tools menu, followed by the Add Passenger submenu. The Passenger Properties dialog will be displayed:



Enter the passenger's name and some descriptive notes if required, then click OK.

Once you've created the passenger record, you need to initialise a Passenger code-plug to identify him/her. To do this, click the Code Plug menu, followed by the Initialise Plug submenu, and then click the Passenger Plug submenu. Follow the instructions in the Initialise Plug Wizard.

Retrieving Passenger Data

In order to test that your passenger code-plug is set up correctly, you need to do a short trip. Identify yourself as the driver using your blue driver code-plug, start a trip, and then insert the newly created black Passenger code-plug. Complete the trip, and download the trip data into the Fleet Manager Client application.

In order to see that a passenger was identified by the unit, generate a "Passenger Identification Report" by clicking the Reports menu, followed by the Vehicle Reports submenu, and then click the Passenger Identification submenu.

Follow the instructions in the Selection Criteria Wizard, being careful to select the correct vehicle and date/time range.